


# EPUTEC – COMPRESSED AIR TECHNOLOGY PROVIDING SOLUTIONS.



CLEANING THE VAC UNIT ON AN EASY SWITCH

# REMOVE MUFFLER



- ▶ With a 1/8" hex allen key, remove (4) screws around bottom


# REMOVE FILTER MEDIA



1

- ▶ Remove white foam from cylinder to replace.

# REMOVE TOP OF MUFFLER AND FOAM DISK



- ▶ With a 1/8" hex allen key, remove (3) screws around top.
- ▶ Remove the foam disk to replace.

# REMOVE VACUUM GENERATOR MUFFLER AND STEM



- Unscrew from base unit, counter clockwise.


# REMOVE FLOAT HOUSING




- ▶ Unscrew from base unit, counter clockwise.

# CLEAN INSIDE VACUUM GENERATOR.


- ▶ Use a mild detergent to clean internal surfaces with soft materials



1



# REASSEMBLY



1. Reattach the float housing to the bottom of vacuum generator.
2. Reattach the vacuum generator stem and muffler.
3. Reattach the outer muffler housing with the (4) screws



# REASSEMBLY



1. Roll clean foam filter and place inside muffler.
2. Press down toward bottom.

# REASSEMBLY



1. Place clean foam disk on top. Place clean foam disk on top.
2. Reattach the upper cap with (3) screws

**THE END**